



SUPER ROCKET **SCOOTER™**

USER MANUAL

Age: 3+ years old



Super Space Scooter™ User Manual

Thank you for purchasing the Prime Super Rocket Scooter. For the best riding experience, please read this user manual carefully before you ride and keep this manual for reference.



Product Specifications

Product Size:	24"L x 32"H
Material:	Steel + PVC
Tire Size:	4.5 inch
Vapor Jets' Battery:	Li 3.7V 4400mAh
Charging Time:	180 mins
Max Load:	110 lbs
Wheel:	PU LED wheels
N/W:	7.7 lbs
Age:	3+ years old

Precautions


1. To ensure your safety, to prevent falls, imbalance, collision and other accidents, please [carefully read this manual](#).
2. Before riding, please check for loose parts and worn tires. If there is any abnormality, please contact us at service@magic-inmotion.com.
3. To ensure your safety and prevent damage, we recommend that riders weigh **no more than 110 lbs.** (50 kg).
4. Please ride on open, flat, well-lit and dry surfaces, away from motor vehicles and other riders.



WARNING:

- Ages 3+
- Only one rider at a time.
- Do not exceed 110 lbs (50 kg) of weight.
- Initial setup, steering tube installation and adjustments require adult assistance.
- Always wear safety equipment such as helmets, knee pads and elbow pads when riding your scooter and keep the helmet's chin strap securely buckled.
- Always wear shoes.
- Check and secure all fasteners before every ride.
- Ride on smooth, paved surfaces away from motor vehicles.
- Avoid sharp bumps, drainage grates and sudden surface changes. Scooter may suddenly stop.
- Avoid surfaces with sand, water, gravel, dirt and other debris. Wet weather impairs traction, braking and visibility.
- Do not ride at night.
- Avoid excessive speed associated with downhill rides.
- Obey all local traffic and scooter riding laws and regulations.
- Watch out for pedestrians.
- Replace worn or broken parts immediately.
- This product's water vapor jets and speaker are powered by a lithium battery. Due to their small size, lithium batteries can easily be swallowed by children. Ingestion of such batteries have been known to cause death.


Components



Assembling your scooter

1. Attach handlebar to board.

Insert handlebar rod into hole between the two front wheels, facing the micro chip towards the back of the scooter. Push down until you hear a **snapping sound**.



2. Adjust handlebar's height.

Press and hold on silver **lock button** and pull handlebar to desired height.



3. Fill jets with water.


Tilt scooter up **90 degrees**. Push down onto water insert button, and pour no more than **3 ounces** of **distilled** water onto water insert button (pictured).



Using Your Scooter

1. Charge your scooter

by plugging charger into charger port. It takes 180 minutes to fully charge.



2. Push master ON/OFF

to turn on the scooter. This allows you to turn on the jets, sound effects and LED headlight.

3. Turn on jets, sounds and LED headlight

by pressing on the secondary ON/OFF button on the handlebar.



4. Activate LED wheels

by simply riding your scooter.



5. Step on back brake to brake, lightly to slow to a stop, and more forcefully for an abrupt stop.



Taking apart your scooter

1. Power off
by pushing the master ON/OFF



2. Remove handlebar.
Simultaneously push and hold two black **lock buttons** located between the front wheels, then pull out handlebar from above.



For all questions regarding this product, contact us at:
[**service@magic-inmotion.com**](mailto:service@magic-inmotion.com)

